

### **1.**/ Please check you have all the required parts

#### before starting installation:

- 1 X baseplate and actuator kit
- 1 X wiring loom
- 8-10 X cable ties
- 2 X scotch locks please note that soldering is recommended
- 1 X convoluted tubing to protect wiring harness

#### **2.**/ You will need the following tools:

- Screwdriver (to remove tailgate panel)
- Metric socket set (to remove tailgate handle)
- Soldering equipment
- Pliers (to crimp scotch lock wire connectors optional)

### **3.**/ Open tailgate:


Undo 10 screws and remove metal panel to allow access into the inside of the tailgate.








**4.**/ Remove the two nuts that hold the tailgate handle into the tailgate.



**5.**/ Install the base plate and actuator kit using the bolts removed in step 4.








#### **6.**/ Connect wiring loom to actuator

**RED to Red & BLACK to Blue** 



**7.**/ Feed cable out of the tailgate on passenger's side. Use convoluted tubing provided to protect cable.




**8.**/Feed cable along the passenger's side of the vehicle and up into the passenger's foot wel. To gain access into the cab there is a grommet under the passenger's foot well, feed the cable through this grommet. Reach under the carpet beneath the passenger's seat and pull the cable into the cab.






**9.**/ Remove passenger's side door still guard and kick plate to access vehicle's wiring harness.



**10.**/Connect the central locking kit into the vehicle central locking loom

**RED** to **Blue** with **Black** trace & **BLACK** to **Blue** with **Red** trace








11./ Solder the wiring loom into vehicle electrics. You may use the Scotch Lock provided but soldering is recommended. Please note that we advise that any connection is appropriately and securely covered with suitable insulation material.

**12.**/ Test the kit by clicking the central locking and checking that the tailgate locks and unlocks.

Don't click continuously since the motor may over heat and fail. if everything works, replace the still guard, kick plate and tailgate cover.



SJS Pro recommends that installation is done by a qualified auto electrician.

Any electrical faults due to improper installation will not be warranted by SJS Pro Products Co. Ltd.

SJS Pro-Products Co.,Ltd. Latkrabang Estate Export Processing Zone 2, No.10 Chalong Krung 31 Road, Lamplatiew Sub-District, Latkrabang District, Bangkok 10520 Thailand. www.sjscanopy.com

